



Typ V with expansion chamber

- 1. product inlet
- 2. weighted feed gate
- 3. feed shaft (*)
- 4. adjustable inlet chute
- 5. air aspiration opening
- 6. adjustable air deflection plates (*)
- 7. outlet for cleaned product
- 8. observation window
- 9. adjustable air compartment with position indicator
- 10. expansion chamber - light fraction
- 11. discharge airlock over complete machine width
- 12. exhaust air

(*) can be mounted/dismounted depending on the product